

What is the installation manual for LONGi Solar PV modules?

Page 1 Installation Manual for LONGi Solar PV Modules... o This manual elaborates on installation and safety use information for PV power generating modules (hereinafter referred to as module) of LONGi Solar Technology Co., Ltd. (hereinafter referred to as LONGi). Please abide by all safety precautions in this guide and local regulations.

Can LONGi Solar modify the product manual or installation manual?

LONGi Solar reserves the rights for modifying the product manual or installation manual without notice in advance. If customers fail to install modules as per the requirements set forth in this manual, the quality warranty provided for customers during sales shall become invalid.

What is the application level of LONGi Solar module?

The application level of LONGi Solar module is Class II, which can be used in systems operating at > 50 V DC or > 240 W, where general contact access is anticipated; When the modules are for rooftop application, it is necessary to take the overall fire rating of the finished structure as well as operation and maintenance into account.

Can Longi photovoltaic modules produce DC current under sunlight?

Page 9 INSTALLATION MANUAL FOR LONGi PHOTOVOLTAIC MODULES OF DG 3.4 Electrical Performance Safety PV modules can produce DC current under sunlight. Any contact of exposed metal at module's wiring parts may result in electrical shock or burn. Any contact of 30 V or larger DC Voltage can be fatal.

How to unpack LONGi Solar modules?

Open LONGi's packaging cartons as per unpacking instructions provided by LONGi Solar. Do not hold the junction box or cables to lift the entire module in any case. Standing or walking on modules is strictly prohibited. Do not drop one module onto another module. To avoid any damage to the front glass of a module, do not put heavy objects on it.

What if a Longi PV module is broken?

To inform the LONGi customer service personnel within two weeks when modules are found broken or other significant abnormality. Refer to the "LONGi PV Module Operation and Maintenance Manual" for details on module maintenance.

responsibility. LONGi reserves the rights for modifying product manual or installation manual without notice in advance. If customers fail to install modules as per requirements set forth in ...

Page 1 Installation Manual for LONGi Solar PV Modules...; Page 2 o This manual elaborates on installation and safety use information for PV power gener- ating modules (hereinafter referred ...

View and Download LONGI LR6-60 M Series installation manual online. Solar PV Modules. LR6-60 M Series solar panel pdf manual download. Also for: Lr6-72 m series, Lr6-60bk m series, Lr6-72bk m series, Lr6-60hv m series, Lr6-72hv m ...

Suntech Module Installation Manual 2024_V1.3_EN ... and control specifications connected to the PV output, it should be multiplied by a reasonable factor, and the safety factor reference value ...

Web: <https://gennergyps.co.za>